

The Horisontstep - Fixed console

Technical data and product info.

Art. No: Various

The flexible sitestair.

Use our loose steps/buildingsteps for a very easy and rational way of building your stairs in desired hights. Offering both fixed angle of 42° and the flexible variant the possibilities are endless.

Ofcourse slipery proff and galvanized.



Easy to assemble, only the first step needs to be leveled / measured, the remaining is "clamped" quickly together with the previous step.



Non-slip construction of expanded sheet metal with large penetration of snow and dirt.



Hot dip galvanized.

All our steps with fixed console are stackable.

HP100 700x200mm & HP101 900x200mm delivers 100pcs per EUR pallet. HP102 1200x200mm - 45pcs per EUR pallet.

Art.no	Size	Angle	Weight
HP100	700x200mm	42°	3,9kg
HP101	900x200mm	42°	5,6kg
HP102	1200x200mm	42°	7kg

Accessories: HP106 Post for building steps.



Horisont Safety Systems AB • Ängsgatan 11 • 828 32 Edsbyn info@horisontsafety.se Telefon: +46 (0) 271-212 75 (Växel) www.horisontsafety.se







Formula for fixed console 42°

This is how you calculate your stair made from The Horisontstep of 42°

Art. No: HP100, HP101, HP102

NUMBER OF STEPS = Total hight times 5 This gives every step the hight of 20cm.

Exampel: Hight 3,5m gives you the following: 3,5 times 5 = 17,5 = 18 Steg.



LENGHT ON YOURE WOODEN SIDERAILS = Number of steps + 1 times 0,3m.

Exampel: 18+1 = 19 times 0,3m = 5,7 Meter.

If following this example your stairs should have 18 steps and your siderails are to be 5,7 meter.

Use high quality screw when building your flexible stair, we recommend atleast size 6x75mm

HP106 Post for our loose steps/building steps, an easy and qick way to build a firm and steady handrail for your flexible sitestair. We recommend one post every 150cm.



Horisont Safety Systems AB • Ängsgatan 11 • 828 32 Edsbyn info@horisontsafety.se Telefon: +46 (0) 271-212 75 (Växel) www.horisontsafety.se

